VROCA Button

Visual Reinforcement Operant Conditioning Audiometry



VROCA Button



USB receiver

A big button the child presses

The child presses the button when they hear the sound, and the Flex monitor rewards them. The button sends its signal wirelessly to the monitor that has the USB receiver plugged in.

No pairing. No batteries. Ever.

It comes pre-programmed for Flex VRA, and each press powers itself from the push of the button.

Setup

1 Plug in the receiver

Plug the USB receiver into an open USB port on the Flex monitor you want the button to activate. Only that monitor responds to the button.

2 Place the button

Put the button where the child can reach it easily, for example on the table in front of them.

3 Set the time (optional)

Each press plays for **4 seconds**. To change it, tap the screen, select **Setup**, and set **VROCA / Big Button activation** under **Timing** on the **VRA** page (1 to 15 seconds).


Using it



×1

Press once

One press activates the monitor for the set time. There's no need to hold the button down.



With DVRA

Tap **DVRA** on the on-screen menu. The monitor shows a still picture (a curtain, a box or an egg). Each press reveals the reward behind it. Tap **DVRA** again to go back to VRA.



Stop unwanted presses

If the child presses when you don't want a reward, **hold the Custom button** on the remote. Activations are blocked for as long as you hold it.

Need help? Call Flex VRA at **512-777-0016** or email **sales@flexvra.com**.