

User Guide: The Remote

Pairing and Unpairing

Flex VRA utilizes a zoned radio-frequency (RF) wireless protocol that operates on 433 MHz. This means that once we bond a remote with a receiver USB, they will remain in communication forever unless they should be manually unpaired in the future.

Up to 6 USB receivers can pair to 2 remote controls and 1 audiometer integration cable simultaneously.



CLEARING REMOTE

To completely erase all pairing data from the remote control, hold down the Light On Button  and the Custom Button  together for 5 seconds. Once the red light flashes 3 times, the remote has successfully been cleared.

Note: Doing this procedure will remove all connected USB receiver data from the remote control. You will need to repair all receivers that you want to communicate with this remote.

RedLight Flash x3



CLEARING USB RECEIVER

To erase remotes pairing data from the USB receiver, hold the pairing button on the USB for three seconds and release. The red light inside the USB receiver will flash three times. The USB receiver is now cleared and can repair to up to 2 new remote controls and 1 Audiostar Pro cable.



PAIRING REMOTE TO USB RECEIVER

STEP ONE

Pairing

Hold down the Light On Button  and the Lights Only Button  together for 5 seconds. Once you see a red flashing light at the top of the remote, you have entered pairing mode.

Slow Blinking Red Light



STEP TWO

While the remote is in pairing mode (flashing red light) give a quick press on the pairing button on the receiver USB.

Note: Holding the pairing button for three seconds will clear any pairing data from the USB receiver.



STEP THREE

After pressing the receiver USB button, the remote will continue to flash the red light 3-4 times and then it will flash yellow. This signifies that pairing has been successful!

Yellow Light Flash



PRO TIP

If desired, each remote can be setup to operate on 8 different channels. This should only be used in the extremely rare case that another non-VRA device should interfere with the remote control. To set the remote to a new channel, hold down the Lights Off and Volume Up key for 5 seconds and the light begins to flash. Then proceed with pairing.